Provisioning A Valcom VE8090R SIP Intercom Controller

Use this guide to provision a Valcom VE8090R as a generic SIP extension in your NocTel account.

Create a Generic SIP Extension:

- 1. In the control panel Click Extension.
- 2. Click Add a new Extension.
- 3. Locate the Generic SIP Device area and click Add Device.
- 4. Give the extension a name and number by click the pencil icon. Click the Save button when finished.
- 5. At the bottom of the page under the section "How to Configure Your Generic SIP device" you will find the information that will need to be entered into the VE8090R's GUI for the device to connect to noctel.

Input the SIP Credentials in the VE8090R

- 1. Login and access the GUI for the VE8090R.
- 2. Ensure your VE8090R is correctly configured on the network including IP, Subnet, Gateway and DNS servers.
- 3. Navigate to the **SIP** tab for the SIP Intercom Controller.
- 4. Enter the following information in the corresponding fields:

VE8090R Fields	NocTel Generis SIP credentials
Authentication Name	NocTel SIP Username
Secret	NocTel SIP Password
SIP Server - Primary	NocTel SIP Host
Keep Alive Timers (secs)	60

IVIP-102B IP Solutions Setup Tool					-		×
<u>File</u> <u>Communications</u> <u>Device</u> Sec <u>u</u> r	ity <u>P</u> rogramming <u>S</u> ystem Co	<u>n</u> flicts <u>H</u> elp					
ᆋ 🗟 📮 🤱 · 🗢 4	- 15 🎶 🕅 🖬 💷	1					
Job Information							
	Summary Properties Network Tim	ne Channels Rela	vs SIP				
SIP Intercom Controller				CID M	T. T.		
00-D0-5F-03-71-28				SIP Mo	de: Trunk		~
🖃 00-D0-5F-03-75-3A							
	Authentication Name:	<noctel sip="" td="" userr<=""><td>name></td><td></td><td></td><td></td><td></td></noctel>	name>				
	Secret:	<noctel passy<="" sip="" td=""><td>word></td><td></td><td></td><td></td><td></td></noctel>	word>				
	Realm:						
	SIP Servers:		Server	Po	rt CO		
	Devision III	Primary	<nociei host="" sip=""></nociei>	500	50		
		Backup 1		50	50		
	DNS SRV:	Backup 2		500	50	-	
					-	-	
	Busy Message:					~	
	Call Fwd Busy (302):				-		
	Outbound Proxy:			Outbound Port:	5060		
	Keep Alive Timer (secs):	60		Options Timer (secs):	0		
	SIP Port:	5060		Idle Timeout (secs):	0	~	
	RTP Port:	20000		Max Call Timer (secs):	0	~	
Legend -							
- Status Unknown							
 Verification Required 	Auto Destination:						
- Error Status		_					
 Update Required Reset Required 	Pre-Announce Tone:						
🖃 - Rescan Required							
Invalid Password							
Find device in tree	Defaults			Сору 🖌	Apply	X Cano	cel
3 devices detected, 3 devices loaded			Ethernet :	Intel(R) PRO/100+ PCI	Adapter - 1	92.168.10	00.250

- Click Apply in the VE8090R's GUI.
 Let the device reboot. It should now show as online in the NocTel Control panel.

Related articles

- Call Parking
- Provisioning and Setup of Grandstream HT801 or HT802 ATA
- Transferring a Call Directly to Voicemail
- Voicemail Setup
- Call Forwarding