## How to Disable Call Waiting (and Call Waiting Tone) on Cisco SPA 112.

Use the following guide to disable call waiting and the call waiting tone on Cisco SPA 112.

- 1. Log in to the phone adapter configuration utility by navigating to the device's IP address. Use the username "admin" and password "8675309" at the login screen.
- Navigate to Voice and then to the user you want to change, either User 1 or User 2. The users correspond with line 1 and line 2 on the device.
  Scroll down to the "Supplementary Service Settings" area.

	oo ooningo		_
CW Setting:	yes 👻	Block CID Setting:	no 🔻
Block ANC Setting:	no 👻	DND Setting:	no 👻
CID Setting:	yes 👻	CWCID Setting:	yes 👻
Dist Ring Setting:	ves -	Message Waiting:	no 🔻

- 4. Set the CW setting to NO using the dropdown box.
- 5. Click **Submit** to save your changes. *The device will reboot.*

## **Related articles**

- Provisioning and Setup of Grandstream HT801 or HT802 ATA
- Provisioning a Cisco ATA/SPA
- How to Disable Call Waiting (and Call Waiting Tone) on Cisco SPA 112.
- Resetting a Cisco ATA to Factory Default
- Quality of Service